

WPG CONCEALED CEILING SYSTEM

INSTALLATION INSTRUCTIONS

1. Fix the Furring Channel Track (WPG CWPG-FCT1630 or WPG CWPG-FCT2830) around the ceiling perimeter.
2. Secure Suspension Rod Brackets (CWPG-SRBA or CWPG-SRBP) in a 1200mm x 1200mm grid pattern with the first Top Cross Rail within 200mm of the wall.
3. Cut the Suspension Rod Soft Galvanised 5mm CWPG-SRSG536 in the required lengths, bend and hook them into the Suspension Rod Brackets.
4. Slide the Suspension Clip TCR (CWPG-TC) or Suspension Clip Side Mounted TCR (CWPG-SMTC) onto the bottom end of the rods.
5. Twist the Top Cross Rail (Main Bar) (CWPG-TCR36 or CWPG-TCR48) into the Suspension Clip TCR.
6. Fit a Locking Key (CWPG-LK) to the Furring Channel (CWPG-FCTxxxx) and then click into the Top Cross Rail.
7. Fix the Furring Channel to the Top Cross Rail at 600mm maximum spacings, or to suit the ceiling lining. Make sure there is 10mm clearance between the wall to the end of the Furring Channels.
8. Level the Furring Channels by squeezing and sliding the Suspension Clip tabs on the Suspension Rods.
9. Ensure the Top Cross Rail (Main Bar) is braced against the wall using a piece of Top Cross Rail.

Note: "xx" is shown in the Figure below where a number of different size Top Cross Rails, Furring Channels and Furring Channel Track are available, choose your part from the WPG Catalogue.







